

DESCRIPTION

COIL-X is formulated for extra heavy duty cleaning, and has self rinsing properties. This 100% biodegradable alkaline detergent product has excellent soil suspending qualities that allow dirt to rinse off freely, whether it is flushed off manually or with the condensate water.

DIRECTIONS

For extremely dirty coils, scrubbing may be necessary for thorough cleaning. If unit is in use, rinsing may be omitted as the condensate water will flush the unit clean.

HEAVY SOIL - Use as supplied, or up to a one to four dilution with water.

MEDIUM SOIL - Use a dilution ratio between one to five and one to ten with water.

PRESSURE WASHER - A ratio between one to fifteen and one to forty (40) dilution with water is recommended.

WECHEM, INC.

5734 Susitna Dr. • Harahan, LA 70123

504.733.1152 • 1.800.426.0512

FAX 504.733.2218 • www.wechem.com

WECHEM® Engineered Chemistries
SUPERIOR SOLUTIONS

COIL-X™

**SELF RINSING
COIL CLEANER**

- **CONCENTRATED**
- **NON-ACID**
- **NON-FLAMMABLE**
- **SELF RINSING**
- **100% BIODEGRADABLE**

WARNING

**KEEP OUT OF REACH OF CHILDREN.
FOR INDUSTRIAL AND INSTITUTIONAL USE ONLY.**
(SEE RIGHT PANEL FOR ADDITIONAL CAUTIONS AND FIRST AID STATEMENTS.)

NET CONTENTS: U.S. GALLONS



WARNING

May be harmful if swallowed. Causes skin irritation. Causes eye irritation. May cause respiratory irritation. Wear protective gloves/protective clothing/eye protection/face protection. Dispose of contents/container in accordance with all local, regional and international regulations.

IF SWALLOWED: Immediately call a POISON CENTER or doctor/physician. Rinse mouth. Do NOT induce vomiting.

IF ON SKIN (or hair): Remove/Take off immediately all contaminated clothing. Rinse skin with water/shower. Wash contaminated clothing before reuse.

IF INHALED: Remove victim to fresh air and keep at rest in a position comfortable for breathing.

IF IN EYES: Rinse continuously with water for several minutes. Remove contact lenses if present and easy to do. Continue rinsing. Immediately call a POISON CENTER or doctor/physician.

READ SAFETY DATA SHEET BEFORE USE.

SCAN FOR SDS



7 38435 20619 2