

DESCRIPTION

POLY D is specifically formulated to counteract problems associated with the use of waste water and water treatment polymers. It is ideally suited for use as an anti-blinding agent in de-watering belt press operations. The continuous injection of **POLY D** at Wechem's recommended dosages will end belt blinding, increase porosity, increase process efficiency and produce drier sludge cakes. It may also be used to disperse polymer residues in polymer tanks, polymer lines, cooling towers and spill areas.

This product is neutral in pH and contains **NONE** of the following ingredients:

Caustic Salts	Solvents
Sodium Metasilicate	Mineral Acids
Sodium Carbonate	Ammonia

DIRECTIONS

For Polymer Spills - Using low pressure sprayer or hose & nozzle assembly, apply to polymer spills. Let sit 15 to 30 minutes. Spray off using high pressure sprayer.

For Belt Wash Systems - Inject **POLY D** into system using a suitable chemical injection metering pump. A working dosage of 1 gallon **POLY D** up to 32,000 gallons of wash water is recommended.



POLY D

Polymer Dispersant & Belt Wash Anti-Blinding System



WARNING
KEEP OUT OF REACH OF CHILDREN.
FOR INDUSTRIAL AND INSTITUTIONAL USE ONLY.
(SEE RIGHT PANEL FOR ADDITIONAL CAUTIONS AND FIRST AID STATEMENTS.)

NET CONTENTS: U.S. GALLON



WARNING

Harmful if swallowed. Causes skin irritation. Causes eye irritation. May cause respiratory irritation.

Avoid breathing dust/fume/gas/mist/vapors/spray. Do not get in eyes, on skin, or on clothing. Wash thoroughly after handling. Use personal protective equipment as required.

IF SWALLOWED: Rinse mouth. Do NOT induce vomiting. Call a POISON CENTER or doctor/physician if you feel unwell.

IF ON SKIN (or hair): Remove/Take off immediately all contaminated clothing. Rinse skin with water/shower.

IF INHALED: Remove victim to fresh air and keep at rest in a position comfortable for breathing. Call a POISON CENTER or doctor/physician if you feel unwell.

IF IN EYES: Rinse continuously with water for several minutes. Remove contact lenses if present and easy to do. Continue rinsing. If eye irritation persists: Get medical advice/attention.

READ SAFETY DATA SHEET BEFORE USE.



WECHEM, INC.
5734 Susitna Dr.
Harahan, LA 70123
504.733.1152
800.426.0512
FAX 504.733.2218
www.wechem.com

