DESCRIPTION

FLEET 150 is the first step in a two-step cleaning system designed to be used with the Wechem two-step, cold water, high-pressure washer. This system was designed to clean heavy-duty equipment and over-the-road trucking equipment, such as truck trailers. When used as directed, this system is the most efficient cleaning system available today.

DIRECTIONS

Place the #1 suction hose directly into container. The pressure cleaning system will automatically dilute concentrate to the proper cleaning strength. Apply FLEET 150 onto a dry vehicle surface from the bottom up. Avoid contact with glass surfaces.

NOTE: This product contains Oxalic Acid and should not be used on glass, polished or anodized aluminum surfaces. Clean these surfaces with FLEET 200 only.





WECHEM[®] Engineered Chemistries SUPERIOR SOLUTIONS

INFORMATION ONLY



STEP 1 In the Wechem 2-Step Cleaning System

FASTEST CLEANING SYSTEM AVAILABLE

DANGER: CORROSIVE KEEP OUT OF REACH OF CHILDREN. FOR INDUSTRIAL AND INSTITUTIONAL USE ONLY. (SEE RIGHT PANEL FOR ADDITIONAL CAUTIONS AND FIRST AID STATEMENTS.)

NET CONTENTS: U.S. GALLON



DANGER: CORROSIVE

May be harmful if swallowed. Causes severe skin burns and eve damage. May cause respiratory irritation. Read before Do lahel use. not breathe dust/fume/gas/mist/vapors/spray. Do not get in eyes, on skin or on clothing. Wear protective gloves/protective clothing/eye protection/face protection. Do not mix with any other cleaner or chemical.

IF SWALLOWED: Immediately call a POISON CENTER or doctor/physician. Rinse mouth. Do NOT induce vomiting. IF IN EYES: Rinse continuously with water for several minutes. Remove contact lenses if present and easy to do. Continue rinsing. Immediately call a POISON CENTER or doctor/physician.

IF ON SKIN (or hair): Remove/Take off immediately all contaminated clothing. Rinse skin with water/shower. If skin irritation occurs: Get medical advice/attention. IF INHALED: Remove victim to fresh air and keep at rest in a position comfortable for breathing. Call a POISON CENTER or doctor/physician.

READ SAFETY DATA SHEET BEFORE USE.

Proper Shipping Name: UN 1760, Corrosive Liquids, N.O.S. (Oxalic Acid), 8, PG III

WECHEM, INC. 5734 Susitna Dr. Harahan, LA 70123 504.733.1152 800.426.0512 Fax 504.733.2218 www.wechem.com

10/16

