

**DEFOAMER** is a water-dilutable silicone anti-foam emulsion used to suppress foam. It contains 5% active silicone defoamer in a non-ionic emulsion, and can be used in quantities up to 100 parts per million.

**DEFOAMER** is also often used to suppress foam in various chemical processing applications, cooling towers and industrial cleaning.

### HOW TO USE -

**DEFOAMER** should always be diluted with water or with a portion of the foamer.

### TO DILUTE -

Stir or agitate **DEFOAMER** before using. Dilute the required amount of **DEFOAMER** with 1.5 volumes of water. Slowly add the water or foamer and stir gently until a uniform mixture is obtained. Use the diluted **DEFOAMER** within eight hours. Longer storage may cause the emulsion to break and lose anti-foam efficiency. If longer storage is necessary, stir the mixture frequently.

**NOTICE:** The customer is responsible for determining the proper personal protective equipment needed for their particular use of this material



Engineered Chemistries  
SUPERIOR SOLUTIONS

# DEFOAMER™

## Foam Suppressor

- Water Dilutable
- Silicone Anti-foam
- Non-Ionic Emulsion

### WARNING

**KEEP OUT OF REACH OF CHILDREN  
FOR INDUSTRIAL AND INSTITUTIONAL USE ONLY.**  
(SEE RIGHT PANEL FOR ADDITIONAL CAUTIONS AND FIRST AID STATEMENTS.)

NET CONTENTS: U.S. GALLONS



### WARNING

Causes skin irritation. Causes eye irritation. May cause respiratory irritation.

Wash thoroughly after handling. Use personal protective equipment as required. Dispose of in accordance with local/regional/national/international regulations.

**IF SWALLOWED:** Rinse mouth. Do NOT induce vomiting. Call a POISON CENTER or doctor/physician if you feel unwell.

**IF ON SKIN:** Wash with plenty of water. If skin irritation or a rash occurs: Get medical advice/attention. Wash contaminated clothing before reuse.

**IF INHALED:** Remove victim to fresh air and keep at rest in a position comfortable for breathing. Call a POISON CENTER or doctor/physician if you feel unwell.

**IF IN EYES:** Rinse continuously with water for several minutes. Remove contact lenses if present and easy to do. Continue rinsing. If eye irritation persists: Get medical advice/attention.

**FOR FIRE:** Use water spray, carbon dioxide, dry chemical or "alcohol-type" foam.

**FOR SPILL:** Flush with water or cover with absorbent. Prevent runoff. Collect and dispose. Observe government regulations.

**READ SAFETY DATA SHEET BEFORE USE.**

SCAN FOR SDS



MADE IN THE USA

WEICHEM, INC.  
5734 Susanna Dr.  
Haharan, LA 70123  
504.733.1152 800.426.0512  
FAX 504.733.2218  
www.wechem.com



7 38435 20637 6

Rev. 09.2025